

LED MODULE BASE NUMBER FULHAM TM05SQ40xx-X01

COMPATIBLE DRIVERS

Compatible Fulham LED Drivers

Fulham Part Number	Driver Description	# of Modules/Driver	Wiring Diagram
T1UNV0700-40C	700 mA, 40W CC Driver, Universal Input	2	С
T1M1UNV0700-40C	700 mA, 40W CC Driver, Universal Input, 0-10V Dimmable	2	С
T1M13470700-40C	700 mA, 40W CC Driver, 347V Input, 0-10V Dimmable	2	С
TC3MLT0350-50L	350 mA, 50W CC Driver, 120-240V AC Input, 3 output channels	3 (1/Ch)	Е
TCD3MLT0350-55L	350 mA, 50W CC Driver, 120-240V AC Input,3 output channels, 0-10V Dimmable	3 (1/Ch)	Е
T1M4UNV0350-100L/C	350 mA, 100W CC Driver, Universal Input, 4 output channels, 0-10V Dimmable	4 (1/Ch)	Е
T1A4UNV0350-100L/C	350 mA, 100W CC Driver, Universal Input, 4 output channels, DALI, 1 control channel	4 (1/Ch)	Е
T2A4UNV0350-100L/C	350 mA, 100W CC Driver, Universal Input, 4 output channels, DALI, 2 control channels	4 (1/Ch)	Е
T4N4UNV0350-100K/B	350 mA, 100W CC Driver, Universal Input, 4 output channels, DMX/DALI, 4 control channels	4 (1/Ch)	Е
FHS2-UNV-36L	HotSpot2 at 200 - 350 mA output.		

NOTE:

- 1. Subject to rated loading conditions.
- Modules are polarity sensitive.
 Ensure that "positive" from LED Driver is connected to "positive" of LED modules and that "negative" from LED Driver is connected to "negative" of LED modules. Polarities of modules are marked with "+" for positive and "-" for negative.
- 3. List is subject to change without notice.
- 4. Reference Fulham's ThoroLED light engine wiring diagrams sheet.