

This guide contains the instructions on installing the SMARTSET software and drivers. Please follow these instructions carefully to ensure smooth installation of each of these components.

Please download the software and drivers from: www.fulham.com/smartsetdownload

NOTE: After installing the software by following the steps below, plug in the SmartSet TPSB-100 Controller and open the SmartSet program. If the unit did not connect properly a screen like the one shown in image #9 will appear (please note the message on the bottom left corner "Disconnected!"). In order to solve this issue please proceed to close the SmartSet software and follow the steps on pages #4 and #5.

1.0 Software Installation

SmartSet.zip - WinRAR (evaluation copy) File Commands Tools Favorites Options Help		Open File - Security Warning	×
Add Extract To Test View Delete Find Wizard Info	VirusCan Comment SFX	The publisher could not be verified. Are you sure	you want to
SmartSet.zip\Release - ZIP archive, unpacked size 5,615,304 bytes	•	run this software? Setup exe	,
Name	Size Packed Type Modified CRC32	Name: ar\$EXa0.392\Belease\EH.Setting	Fool Setup msi
FH_Setting Tool_Setup.msi	HiteTolder 2,739,712 2,382,593 Windows Installer 12/6/2017 6:55 ACD788BD		ool_secupinisi
I setup.exe	428,032 195,665 Application 12/6/2017 6:55 3C069F2D	Publisher: Unknown Publisher	
		Type: Windows Installer Package	
		From: C:\Users\ereyes\AppData\Local\Tem	np\Rar\$EXa0.3
		Run	Cancel
		This file does not have a valid digital signature that publisher. You should only run software from publis How can I decide what software to run?	verifies its hers you trust.
	Total 3,167,744 bytes in 2 files		
1 Open the zip file	e and double click on the	2 In the pop up window click "Run	"

Open the zip file and double click on the setup.exe file

FULHAM



³In the next screen click "Next"

4 Please read carefully the "End user agreement" in its entirety and click "I agree"

See pages #4 and #5 if the drivers need to be reinstalled

The driver must be properly installed, since it is the software that allows your computer to talk to the controller.

Fulham Co. Inc.: 12705 South Van Ness Ave., Hawthorne, CA 90250 · Telephone: 1-323-779-2980 · Fax: 1-323-754-9060 order@fulham.com www.fulham.com Installation Instructions subject to change without notice. Rev. A Page 1 of 5



GUIDE FOR SMARTSET SOFTWARE INSTALLATION

This guide contains the instructions on installing the SMARTSET software and drivers. Please follow these instructions carefully to ensure smooth installation of each of these components.

Please download the software and drivers from: www.fulham.com/smartsetdownload

NOTE: After installing the software by following the steps below, plug in the SmartSet TPSB-100 Controller and open the SmartSet program. If the unit did not connect properly a screen like the one shown in image #9 will appear (please note the message on the bottom left corner "Disconnected!"). In order to solve this issue please proceed to close the SmartSet software and follow the steps on pages #4 and #5.

1.1 Software Installation

谩 Fulham SmartSet		岁 Fulham SmartSet	
Select Installation Folder		Confirm Installation	
The installer will install Fulham SmartSet to the following folder.		The installer is ready to install Fulham SmartSet on your con	nputer.
To install in this folder, click "Next". To install to a different folder, enter i	t below or click "Browse".	Click "Next" to start the installation.	
Eolder: C:\Program Files (x86)\Fulham Inc\Fulham SmartSet\	Browse Disk Cost		
Install Fulham SmartSet for yourself, or for anyone who uses this comp	uter:		
Everyone			
⊘ Just me			
Cancel < Ba	ck Next >	Cancel	Back Next >

⁵ Chose the folder in which the software must be saved. Chose who can use this software in this computer and click "Next"

Installing Fulham Smart	Set		
Fulham SmartSet is being installed.			
Please wait			
	Cancel	< Back	Next >
	Cancel	< Back	Next >

"Next" when prompted

⁶ Confirm the Installation and click "Next"

Installation Complet	te	Ę
Fulham SmartSet has been succe	essfully installed.	
Click "Close" to exit.		
Please use Windows Update to c	sheck for any critical updates to the .NET F	ramework.
Please use Windows Update to c	sheck for any critical updates to the .NET F	ramework.
Please use Windows Update to c	check for any critical updates to the .NET F	ramework.

Launch SmartSet Program.

 Fulham Co. Inc.: 12705 South Van Ness Ave., Hawthorne, CA 90250 · Telephone: 1-323-779-2980 · Fax: 1-323-754-9060 order@fulham.com
 order@fulham.com
 www.fulham.com

 Installation Instructions subject to change without notice.
 Rev. A
 Page 2 of 5



This guide contains the instructions on installing the SMARTSET software and drivers. Please follow these instructions carefully to ensure smooth installation of each of these components.

Please download the software and drivers from: www.fulham.com/smartsetdownload

NOTE: After installing the software by following the steps below, plug in the SmartSet TPSB-100 Controller and open the SmartSet program. If the unit did not connect properly a screen like the one shown in image #9 will appear (please note the message on the bottom left corner "Disconnected!"). In order to solve this issue please proceed to close the SmartSet software and follow the steps on pages #4 and #5.

SmartSet - F	ulham Setting	Tool							-		×
File Option	ns About								FUL	HA	SП.
Current Set V	oltage Set /	Idvanced Settings	Runtime Info	EM Settings	Ext. NTC	Printing			LightingGlobal	Intelligent. St	istahabin
							(AD		
								-0			
								_			
		1	PROG		Au	to Pro	ogram				
	_	If this mes	sage ap	pears.	/011 W	vill nee	ed to re	einstall th	e drive	rs.	
	<			pearo, 1							
Disconnected!					wai	ting for	connand [Log File Recor	ding + Ver. 1		

FULHAM

1.2 Software Installation

If connection was not successful a message like the one shown in the red rectangle will appear. Please follow instructions on page #4.

* See pages #4 and #5 if the drivers need to be reinstalled

The driver must be properly installed, since it is the software that allows your computer to talk to the controller.



This guide contains the instructions on installing the SMARTSET software and drivers. Please follow these instructions carefully to ensure smooth installation of each of these components.

Please download the software and drivers from: www.fulham.com/smartsetdownload

NOTE: After re-installing the USB driver, plug in the SmartSet TPSB-100 Controller and open the SmartSet program. If the unit did connect properly a screen like the one shown in image #15 will appear (please note the message on the bottom left corner "TPSB-100 connected"). Installation is now complete.

2.0 Driver Installation

SmartSetzip-WinARR (evaluation copy)	Open File - Security Warning
Add Extract To Test View Delete Find Wizard Info VisuScan Comment S7X	Do you want to put this file?
🖸 🗃 SmartSetzipUKSB2COM driver - ZIP archive, unpacked size 5,615,304 bytes 🔹	Do you want to full this file?
Hame Size Packed Type Modified CRC22 Fel tofor ■ F1222_USB_Drive_Stup_CDX2122.ee 2,441,560 2,381,582 Application 5,580/2017.321 DH5H6A9	Name: M driver\FT232_USB_Driver_Setup_CDM2122.exe Publisher: Future Technology Devices International Ltd Type: Application From: C:\Users\ereyes\AppData\Local\Temp\Rar\$EXa0.1 Run Cancel Image: While files from the Internet can be useful, this file type can potentially harm your computer. Only run software from publishers you trust. What's the risk?
EI=C Total 2,447,500 bytes in 1 file	

10 Open the zip file and double click on the FT232_USB_Driver_Setup_CDM2122.exe file





11 In the pop up window click "Run"

13 Click "Next" to continue

12In the next screen click "Extract" in order to unpack the latest driver package available



This guide contains the instructions on installing the SMARTSET software and drivers. Please follow these instructions carefully to ensure smooth installation of each of these components.

Please download the software and drivers from: <u>www.fulham.com/smartsetdownload</u>

NOTE: After re-installing the USB driver, plug in the SmartSet TPSB-100 Controller and open the SmartSet program. If the unit did connect properly a screen like the one shown in image #15 will appear (please note the message on the bottom left corner "TPSB-100 connected"). Installation is now complete.

2.1 Driver Installation

Device Driver In:	stallation Wizard		SmartSet - Fulham Setting Tool	– 🗆 ×
			File Options About	FULHAM
License Ag	reement		Current Set Voltage Set Advanced Settings Runtime Info EM Settings Ent MTC Printing	Lyring. Gene realprit Bullinale
Ŕ	To continue, accept the following license agreement. To read the entire agreement, use the scroll bar or press the Page Down key.			
	IMPORTANT NOTICE: PLEASE READ CAREFULLY BEFORE INSTALLING THE RELEVANT SOFTWARE: This licence agreement (Licence) is a legal agreement between you (Licensee or you) and Future Technology Devices International Limited of 2 Seaward Place, Centurion Business Park, Glasgow G41 1HH, Scotland (UK Company Number SC136640) (Licensor or we) for use of driver software provided by the Licensor(Software).			READ
	BY INSTALLING OR USING THIS SOFTWARE YOU AGREE TO THE I accept this agreement Save As Print I don't accept this agreement	-	PROG Auto Program	
	< Back Next > (Cancel	If this message appears, the installation was suc	CCESSful. • Recording • Ver. 1. 1. 6537.32095;

- 14 Please read carefully the "End user agreement" in its entirety and click "I agree" and finalize installation
- 15 If installation was successful a message like the one shown in the red rectangle will appear. Installation is now complete.