



EMERGENCY BALLAST AND AC BALLAST MUST BE FED FROM THE SAME BRANCH CIRCUIT.
TYPICAL SCHEMATICS ONLY. MAY BE USED WITH OTHER BALLASTS. CONSULT THE FACTORY FOR OTHER WIRING DIAGRAMS

WIRING DIAGRAMS FOR TWO LAMP EMERGENCY OPERATION
TWO-LAMP EMERGENCY OPERATION IS NOT POSSIBLE WITH ALL BALLASTS. CONSULT THE FACTORY FOR ANY BALLAST OTHER THAN THOSE SHOWN.

5. FOUR (4) LAMP RAPID START BALLAST




6. FOUR (4) LAMP INSTANT START BALLAST




WIRING DIAGRAMS FOR EMERGENCY ONLY LUMINAIRES


1. ONE (1) LAMP WITHOUT AC BALLAST




2. TWO (2) LAMP WITHOUT AC BALLAST



3. ONE (1) 4-PIN COMPACT LAMP WITHOUT AC BALLAST



4. TWO (2) 4-PIN COMPACT LAMPS WITHOUT AC BALLAST



**NOTE: GREEN WIRE MUST BE GROUNDED
USE PROPER CAPS TO TAP UNUSED LEADS**

*LIGHTED PUSH BUTTON TEST SWITCH (LPBTS)