











Programmable Constant Power LED Driver

Emergency LED Driver

Input Voltage: 120-277V~, 50/60Hz

Output Voltage Range: 12-55V==

Output Current Range: 73-333mA

• Emergency Power: 4W

Test Switch Indicator: Red Light

IP20

eneral Specifications				
Input Voltage / Frequency	120-277V~, 50/60Hz			
Input Current	100mA Max			
Input Power	3 <u>W</u> <0.85W			
Standby Power				
Input Power Pass-Through Rating (White/Black Lead)	1A			
Max Output Rating (Red Lead)	2A, 55V Max Constant Power 333mA @12V, 73mA @55V 12-55V			
Driver Type				
Current Rated				
Output Voltage Range				
Output Power	4W			
Output Class	LED Class2			
Number of Output Channels	1 Channel FHSCP-TST-WC			
Test Switch Part Number				
Test Switch Indicator	Red Light			
Test Switch Remote Mounting Distance	65.6' (20m) Max. 18AWG Wire + Connector			
Battery ON / OFF				
Wire Type	Input: 18AWG, Output: 18 AWG, Test Switch: 22AWG			
Dry Location	Dry Location Line-Neutral 1kV, Line & Neutral-Ground 2kV			
Input Surge Protection				
Emergency Mode Protections	Battery Over Voltage Protection			
	Battery Under Voltage Protection			
	Output Open Circuit Protection			
	Output Short Circuit Protection			
RFI / EMI	FCC Part 15 ClassA			
Ambient Operating Temperature Range	5°C To 55°C (41°F To 131°F)			
Sound Rating	Α			
Battery Type	LiFePO4			
Battery Voltage	6.4V			
Battery Capacity	2Ah Max			
Battery Charge Current	165mA			
Battery Recharge Time	12 Hours			
Battery Discharge Time	Min 90 Minutes			
IP Rating	IP20			
Service Life	50,000 hours			
Warranty	5 years			
Safety Standards UL924 (USA), CEC, CSA C22.2 No.141-10/cUL				
















Mechanical Data



Overall Dimensions					
Length	5.34" (135.7mm)				
Width	1.69" (42.8mm)				
Height	1.01" (25.7mm)				
Mounting	5.02" (127.4mm)				





Tolerance = \pm [0.5mm]














Accessories


Test Switch: FHSCP-TST-WC



Wall Plate: FHSWLPWH (not included)



Wall plate and screw color: white with black lettering



1."Charge push to Test"plate 2. (2) 6-32 x ½"LG mounting screws















Wiring Diagram



Wiring Diagram (Emergency Only)















Test Switch Indicator Status:

LED Indicators Status	EM Driver Status/Mode		
Solid Red	Normal working in AC mode.		
● Slow Flashing Red, 4s on/1s off	Battery not detected mode.		
● Flashing Red, 1s on/1s off	Battery Failure Detected mode.		
● Flashing Red, 4s on/4 s off	No Load/LED Load Failure mode.		
● Flashing Red, 0.1s on/3s off	Emergency mode.		

Test Switch Operations:

EM Test: Press and hold test button for 1s to enter EM mode for testing in normal AC powered. Press and hold test button for 10s to exit emergency mode.













Guidelines

Grounding

• Driver must be grounded by means of the Driver case.

LED load

Fulham's Hotspot Constant Power Emergency LED drivers are designed to drive passive LEDs, COB's and LED assemblies.
 Proper function is not guaranteed when (LED) loads with active components are used.

Mounting / Cooling

• Above an output power of 4W, the driver needs to be mounted on a heat conductive surface of at least 40cm². Always test if the surface is sufficient enough before installing the driver.

Short-circuit protection

 In case of a short circuit the LED driver switches to protection mode. After the removal of the short-circuit the LED driver will Latch, need restart AC Power.

No-load Operation

In no-load operation the output voltage will not exceed the specified open circuit output voltage.

Hot Swapping

This driver does not support hot swapping of the LEDs

Battery Maintenance

• In order to maintain proper operation and warranty coverage, the battery must be recharged once per year prior to installation.

Warranty

Reference Fulham's limited Warranty: https://cdn.fulham.com/PDFs/Limited-Warranty.pdf

Fulham Co. Inc.: 12705 South Van Ness Ave., Hawthorne, CA 90250 Tel.: 1-323-779-2980 Fax.: 1-323-754-9060. order@fulham.com
Specifications subject to change without notice.

Page 6 of 7
2020-859 Rev F













Part Number Matrix



LED Driver

FHS = FireHorse HotSpot Driver

<u>U</u>

Driver Type

CP = Constant Power

UNV

Input Voltage

UNV = 120V-277V

4W

Power

4W = 4 Watts

Case Type

L = Long Case


Product Image: LED Driver

FHSCP-UNV-4W-L



Packaging

Master Carton



OUTER DIMENSION							
L	V		V	Н			
15.52"(394m	nm)	10.79"(2	274mm)	8.268" (210mm)			
Net Weight	Gross Weight		QL	JANTITY			
18.52lbs. (8.4kg.)	20.72lbs. (9.4kg)			30pcs.			